

NOTES

ChildLife

Escalade Sports®
P.O. Box 889
Evansville, IN 47706

TollFree (800) GO-SWING or (800) 467-9464
Fax (866) 873-3537
E-mail childlifecs@escaladesports.com
Home Page childlife.com

Owner's Manual

NOTE TO INSTALLER: After you have assembled and installed the play system, please give the customer the tools provided and the Owner's Manuals for **both** Everest and Jungle Tower play systems.

rev 5/9/05

EVEREST & JUNGLE TOWER COMBINATION PLAY SYSTEM

RB SD



Pictured: Everest & Jungle Tower Combination (Beam model for 4 swings) with Safety Walls and Swings added.

Congratulations and thank you for purchasing a fine ChildLife® brand play system!

Customer Copy

Step 1. IMPORTANT INFORMATION

The Everest & Jungle Tower combination play system is an Everest play system at one end of the swing support and a Jungle Tower play system at the other end.

To assemble and install this configuration, you **MUST** refer to the Owner’s Manuals (containing Safety Instructions, Maintenance Instructions, and Assembly Instructions) of **both** play systems. These manuals are enclosed. If you do not have both manuals, contact ChildLife for free replacement copies. You can **not** proceed unless you have **both** manuals.

You **must** use the Everest and Jungle Tower manuals that have version dates, indicated in the lower right corner of the last page, of 3/13/03 and 4/5/04 respectively. The Everest manual must include an addendum for Steps 37-44 therein.

Step 2. INVENTORY YOUR BOXES

If you purchased your play system from ChildLife Inc., (rather than from a dealer), find the Packing List in a clear plastic envelope fastened to the red box. Use the Packing List to ensure that you have received all the boxes required to assemble your play system. Each box is identified by a large number on one side, and includes a detailed list of contents. Table 1 on page 3 of this document tells you which boxes you need for Everest & Jungle Tower combination play systems.

If you purchased your play system from a dealer and have questions about which boxes you need, kindly call the dealer, which alone has the details of your specific order.

Step 3. FOLLOW INSTRUCTIONS IN THE TWO MANUALS AS FOLLOWS:

- 1) From the **Everest** play system manual, do Steps 1-36 to assemble the Everest tower.
- 2) From the **Jungle** play system manual, do Steps 1-12 to assemble the Jungle tower. **Note** that you will do **either** Step 11 **or** Step 12 (not both) depending on if you are installing a Crow’s Nest Treehouse at this time. Follow the instructions closely.
- 3) From the **Everest** play system addendum, inserted into your Everest play system manual, do Steps 41-44 to fasten one end of the Swing Beam to the Everest. You will need a helper to hold the other end of the swing beam until you can fasten it to the Jungle later.
- 4) From the **Jungle** play system manual, do Steps 18, 19, 13, and 20 in that order
- 5) From the **Jungle** play system manual, do Steps 21-26
- 6) From the **Everest** play system manual, do Steps 47-52
- 7) From the **Jungle** play system manual, do Step 27

TABLE 1- BOX REQUIREMENTS FOR EVEREST & JUNGLE TOWER COMBINATION PLAY SYSTEMS

Everest & Jungle Combo (Beam model for 1 swing)	Everest & Jungle Combo (Beam model for 3 swings)
Box # SD Red Box - Everest & Jungle Combo	Box # SD Red Box - Everest & Jungle Combo
Box # S1 Tower Uprights (4)	Box # S1 Tower Uprights (4)
Box # S2 Tower Deck & Base	Box # S2 Tower Deck & Base
Box # S3 Tower Tent Crossarms	Box # S3 Tower Tent Crossarms
Box # S4 Safety Wall	Box # S4 Safety Wall
Box # S5 Denali & Everest Top Rails	Box # S5 Denali & Everest Top Rails
Box # S11 Everest Uprights (2)	Box # S11 Everest Uprights (2)
Box # S12 Everest Deck	Box # S12 Everest Deck
Box # S13 Everest Base	Box # S13 Everest Base
Box # S14 Everest 3’ Side Mounts	Box # S14 Everest 3’ Side Mounts
Box # S20 Large Summit Tent	Box # S20 Large Summit Tent
Box # S21 Medium Summit Tent	Box # S21 Medium Summit Tent
Box # 2 Jungle Tower Flats	Box # 2 Jungle Tower Flats
Box # 3 Tower Crossarms	Box # 3 Tower Crossarms
(2) Box # 14 Beam Bracket	(2) Box # 14 Beam Bracket
Box # 16.1 1 Swing Top Beam	Box # 16.3 3 Swing Top Beam
Everest & Jungle Combo (Beam model for 2 swings)	Everest & Jungle Combo (Beam model for 4 swings)
Box # SD Red Box - Everest & Jungle Combo	Box # SD Red Box - Everest & Jungle Combo
Box # S1 Tower Uprights (4)	Box # S1 Tower Uprights (4)
Box # S2 Tower Deck & Base	Box # S2 Tower Deck & Base
Box # S3 Tower Tent Crossarms	Box # S3 Tower Tent Crossarms
Box # S4 Safety Wall	Box # S4 Safety Wall
Box # S5 Denali & Everest Top Rails	Box # S5 Denali & Everest Top Rails
Box # S11 Everest Uprights (2)	Box # S11 Everest Uprights (2)
Box # S12 Everest Deck	Box # S12 Everest Deck
Box # S13 Everest Base	Box # S13 Everest Base
Box # S14 Everest 3’ Side Mounts	Box # S14 Everest 3’ Side Mounts
Box # S20 Large Summit Tent	Box # S20 Large Summit Tent
Box # S21 Medium Summit Tent	Box # S21 Medium Summit Tent
Box # 2 Jungle Tower Flats	Box # 2 Jungle Tower Flats
Box # 3 Tower Crossarms	Box # 3 Tower Crossarms
(2) Box # 14 Beam Bracket	(2) Box # 14 Beam Bracket
Box # 16.2 2 Swing Top Beam	Box # 16.4 4 Swing Top Beam