

ChildLife®

The Ultimate Backyard Play System Since 1945™

VERY IMPORTANT!

Before you install the rungs:

If excessive force is needed to install rungs, they may have swollen due to humidity in transit or storage. Please note that using excessive force to install the rungs may split the ladder rail, causing damage which is not covered under warranty.

Use sandpaper to sand down the diameter of the rungs before installation. You can also lubricate the ends with a bar of household soap. Rungs fit correctly when installed using moderate force and a household hammer.

Please see additional information on the reverse of this page. If the reverse is blank, please call ChildLife at (800) 467-9464 for a free replacement copy.

Squeaky swings??

If swings "squeak" during normal use, lubricate the nylon bushing in the swing hangers with liquid household soap.

Why does our play system "creak" when the children play on it?

Unlike other playsets, only ChildLife® brand play systems are protectively encased in a safe, non-toxic enamel that minimizes maintenance and protects your investment for years to come. For some time after assembly, you may hear the freshly painted surfaces "creak" as their enameled surfaces rub harmlessly against one another. This is normal, and will go away after a few weeks of use.

***Thank you again for choosing a fine
ChildLife® brand play system!***